

PROTOCOL

VitroGel[®] MSC

CAT NO. VHM03, VHM03S

RECOMMENDED MATERIALS AND REAGENTS

- VitroGel[®] MSC (Cat# VHM03)
- Cells
- Cell culture medium
- Conical tubes (15 mL or 50 mL)
- Micropipette; low retention pipette tips
- Centrifuge
- Cell culture plate

3D Cell Culture Protocol

1. Bring VitroGel MSC to room temperature or warm at 37°C.
2. Prepare the MSC suspension in the culture medium.
 - Recommended cell concentration > 0.8 x 10⁶ cells/mL.
 - **Optional:** if culture medium contains critical supplement (e.g. 2% Human Platelet Lysate (HPL), prepare cell suspension with 3X supplement (e.g. 6% HPL).
3. Add 1mL VitroGel MSC to 500 µL cell suspension and gently pipette up and down 5-10 times to mix thoroughly. (Keep VitroGel and cell suspension at 2:1 v/v mixing ratio).
4. Transfer the hydrogel mixture to a well plate. Gently tilt/swirl the well plate to ensure there is an even covering on the bottom of each well. The recommended volume of hydrogel for well plates is list below.

	6 well plate	12 well plate	24 well plate	48 well plate	96 well plate
Volume per well	1200 µL	600 µL	300 µL	150 µL	50 µL

5. Wait 10-15 min at room temperature for a soft gel formation.
(**Note:** During the hydrogel forming process, do not disrupt the hydrogel by tilting or shaking the well plate).
6. Carefully add additional medium to cover the hydrogel. The recommended volume of cover medium for well plates is listed below

	6 well plate	12 well plate	24 well plate	48 well plate	96 well plate
Volume per well	1200 µL	600 µL	300 µL	150 µL	50 µL

7. Place the well plate in an incubator and change the cover medium every 48 hours.
(**Note:** We recommend to only change 50-80% of the top medium without disturbing the hydrogel).



Hydrogel-Cell Bead Protocol

1. Bring VitroGel MSC to room temperature or warm at 37°C.
2. Prepare the MSC suspension in the culture medium.
 - Recommended cell concentration > 0.8×10^6 cells/mL.
 - **Optional:** if culture medium contains critical supplement (e.g. 2% Human Platelet Lysate (HPL)), prepare cell suspension with 3X supplement (e.g. 6% HPL).
3. Add 1mL VitroGel MSC to 500 μ L cell suspension and gently pipette up and down 5-10 times to mix thoroughly. (Keep VitroGel and cell suspension at 2:1 v/v mixing ratio).
4. Add cell culture medium to the well plate. The recommended volume of hydrogel for well plates is list below.

	6 well plate	12 well plate	24 well plate	48 well plate	96 well plate
Volume per well	3000 μ L	1500 μ L	750 μ L	300 μ L	100 μ L

5. Using a pipettor with a 100 μ L tip, carefully pipette the hydrogel-cell mixture into the well plate as droplets. (roughly 5-10 droplets per 100 μ L of hydrogel-cell mixture).
Optional: control the final size of hydrogel-cell beads by adjusting the volume of the droplets: for small beads, 1-5 μ L per droplet, for large beads, 20-50 μ L per droplet).
Tip: Press the pipette plunger to create a droplet on the pipette tip, lower the pipette tip to release the droplet by contacting the surface of culture medium.
6. Place the well plate in an incubator and change the medium every 48-72 hours.
(Note: We recommend to only change 50-80% of the top medium without disturbing the hydrogel beads).

2D Hydrogel Coating Protocol

1. Bring VitroGel MSC to room temperature or warm at 37°C.
2. Add 1mL VitroGel MSC to 500 μ L cell culture medium and gently pipette up and down 5-10 times to mix thoroughly.
(Note: Keep VitroGel and cell medium at 2:1 v/v mixing ratio).
Optional: If culture medium contains critical supplement (e.g. 2% Human Platelet Lysate (HPL)), prepare culture medium with 3X supplement (e.g. 6% HPL) to mix with VitroGel MSC to get 1X final concentration of supplement).
3. Transfer the hydrogel mixture to a well plate. Gently tilt/swirl the well plate to ensure there is an even covering on the bottom of each well. The recommended volume of hydrogel for well plates is listed below.

	6 well plate	12 well plate	24 well plate	48 well plate	96 well plate
Volume per well	1200 μ L	600 μ L	300 μ L	150 μ L	50 μ L

4. Wait 10-15 min at room temperature for a soft gel formation.
(Note: During the hydrogel forming process, do not disrupt the hydrogel by tilting or shaking the well plate).
5. Carefully add medium with cells on top of hydrogel (Recommend cell concentration of 5×10^5 cells/mL). The recommended volume of cell medium for well plates is listed below.

	6 well plate	12 well plate	24 well plate	48 well plate	96 well plate
Volume per well	1200 μ L	600 μ L	300 μ L	150 μ L	50 μ L

6. Wait 10-15 min at room temperature for a soft gel formation.
(Note: During the hydrogel forming process, do not disrupt the hydrogel by tilting or shaking the well plate).



Protocol for Cell Recovery from VitroGel MSC

- For 3D cell culture and 2D hydrogel coating, refer to **Protocol-1** of the VitroGel Cell Recovery Solution Protocol.
- For hydrogel-cell bead culture, refer to **Protocol-2** of the VitroGel Cell Recovery Solution Protocol.”

Your use of this product is subject to our LIMITED USE LICENSE, LIMITED WARRANTY AND TERMS OF SALE AGREEMENT which can be found at <https://www.thewellbio.com/terms-and-conditions>. If your use is not permitted by our Limited Use License, please contact us for authorization of your use. If you do not agree to the terms of our Limited Warranty and our Terms of Sale should return the product in acceptable conditions to the seller for a refund.



Corporate Headquarters

TheWell Bioscience Inc.
675 US Highway 1
North Brunswick, NJ 08902

For research use only

US TF: +1 866.3D.CELLS TEL: +1 973.855.4955 | support@thewellbio.com | www.thewellbio.com

Page 3 of 3

Rev 1.0